
Meridian 1

Meridian 1

Hardware replacement

Document Number: 553-3001-520

Document Release: Standard 13.00

Date: October 1997

© 1993, 1997

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

January 29, 1990

Standard, release 1.0.

July 31, 1990

Standard, release 2.0.

December 1, 1991

Standard, release 3.0. This document is reissued to include technical content updates. Due to the extent of the changes, revision bars are omitted.

December 31, 1992

Standard, release 4.0. New information and changes to technical content are noted by revision bars in the margins.

April 1, 1993

Standard, release 5.0. New information and changes to technical content are noted by revision bars in the margins.

August 1, 1993

Standard, release 6.0. Changes to technical content are noted by revision bars in the margins.

April 1, 1994

Standard, release 7.0. Reissued to include the information for Meridian 1 option 61C. Changes to technical content are noted by revision bars in the margins.

December 1994

Standard, release 8.0. This document is reissued to include updated information on the Small Systems Multi Disk Unit (SMDU), Meridian 1 option 51C, and edits. Changes to technical content are noted by revision bars in the margins.

December 1994

Standard, release 9.0. Reissued for technical content.

July 1995

Standard, release 10.00. This document is reissued to include international information to create a global NTP, Meridian 1 option 81C, and minor text edits. Changes to technical content are noted by revision bars in the margins.

December 1995

Standard, release 11.00. This document is reissued to include information on the NT9D19 Call Processor Card and the circuit card replacement procedure for replacing an IOP and a CMDU with an IOP/CMDU.

August 1996

Standard, release 12.00. This document is reissued to include Call Processor (CP) card memory requirements for Release 22 and other technical information.

October 1997

Standard, release 13.00. This document is reissued to include information on the NT5D10 Call Processor Card, the NT5D61 Input/Output Disk Unit with CD-ROM (IODU/C), and the NT5D30 Dual Intergroup Switch (DIGS) card. Changes are noted by revision bars in the margins.

Contents

About this document	1
References	1
Accessing the system	3
Access through the system terminal	3
Access through the maintenance telephone	5
Hardware replacement guidelines	9
Precautions	9
Power equipment	9
Circuit cards	9
Data disks	11
Options 51C, 61C, 81, and 81C cable guidelines	13
Replacing equipment	15
Removing module covers and pedestal grills	15
Module covers	15
Pedestal grills	17
Removing UK air exhaust/intake grills	17
A0321130 Fan Unit	19
A0378252 Battery Pack Assembly	22
NTAG26 Extended Multi-frequency receiver	24
NT5K09 Quad Digitone Receiver	26
NT5K10 Dual Loop Peripheral Buffer Card	28
NT5K1106 Enhanced Peripheral Equipment Card Cage	29

Replacing the NT5K21AA Circuit Card	33
NT1P61 Fibre Superloop Network Card	35
NT1P62 Fibre Peripheral Controller Card	37
Replacing NT5D10 68060 Call Processor (CP) Cards in systems equipped with NT5D61 IODU/C cards	39
NT5D10 68060 Call Processor (CP) card	45
NT5D12AA Dual DTI/PRI (DDP)	50
Removing the DDP card	50
Installing the DDP card	51
NT5D20 IOP/CMDU	53
Replacing the NT6D63 IOP and the NT6D64 CMDU with the NT5D20 IOP/ CMDU	61
NT5D30AA Dual InterGroup Switch (DIGS) card	72
NT6D3903 CPU/Network Module Card Cage	76
NT6D40, NT6D41, NT6D42, NT6D43 Power Supply DC	81
NT5D61 Input/Output Disk Unit with CD-ROM (IODU/C)	82
Performing a data dump	82
Splitting the Cores	83
Replacing the IODU/C in a redundant system	85
Replacing the IODU/C in an option 51C	90
Completing the upgrade	101
NT6D52 Rectifier -48 V/30 A	102
NT6D6008 Core and NT9D1103/NT5D2103 Core/Network Card Cage	106
NT6D6003 Core Bus Terminator Card	122
NT6D63 I/O Processor Card	124
NT6D64 Core Multi Drive Unit	130
NT6D65 Core to Network Interface Card	132
NT6D66 Call Processor Card	135
NT7D10 Power Distribution Unit DC	141
NT7D14, NT8D06, NT8D21, NT8D29 Power Supply AC	146

NT7D15 System Monitor	148
NT7D67CB Power Distribution Unit DC	150
NT7R51 Local Carrier Interface Card	156
NT7R52 Remote Carrier Interface Card	158
NT8D01 Controller Card	160
NT8D02, NT8D03, NT8D09, NT8D14, NT8D15, NT8D16 Intelligent Peripheral Equipment Card	162
NT8D04 Superloop Network Card, QPC414 Network Card	165
NT8D17 Conference/TDS Card	167
NT8D18 Network/DTR Card	169
NT8D19 Memory/Peripheral Signaling Card	171
NT8D22 System Monitor	172
NT8D41 Dual Port Serial Data Interface Paddle Board	174
NT8D46AC Thermostat Harness	176
NT8D46AM, NT8D46DC Air Probe Harness	182
NT8D52AB, NT8D52DD Pedestal Blower Unit	186
NT8D53AB Power Distribution Unit AC	188
NT8D53AD Power Distribution Unit	191
NT8D56AA, NT8D56AC, NT8D57 Module Power Distribution Unit	194
NT8D1103 CE/PE Module Card Cage	196
NT8D1303 PE Module Card Cage	199
NT8D3403 CPU Module Card Cage	202
NT8D3503/NT8D3507 Network Module Card Cage	206
NT8D3703 IPE Module Card Cage	214
NT8D33 Small Systems Multi Disk Unit	217
Replacing NT9D19 68040 Call Processor (CP) Cards in systems equipped with NT5D61 IODU/C cards	219
NT9D19 68040 Call Processor (CP) card	225
NT9D34 Enhanced Mass Storage Interface Card	230

NTBK51AA Downloadable D-Channel Daughterboard	233
Removing the DDCH Daughterboard	233
Installing the DDCH Daughterboard	233
NTND01 Integrated CPU/Memory Card	236
NTND02 Misc/SDI/Peripheral Signaling Card	238
NTND08, QPC939 ROM Card	240
NTND09, QPC583 Memory Card	242
NTND10, QPC581 Changeover and Memory Arbitrator Card	244
NTND15, NT8D68 Floppy Disk Unit	247
NTND16, NT8D69 Multi Disk Unit	249
NTND31 ROM Card	251
P0699798 Air Filter	253
QMM42 Security Data Cartridge	255
QPC43 Peripheral Signaling Card	258
QPC215 Segmented Bus Extender Card	260
QPC412 InterGroup Switch Card	262
QPC441 Three-Port Extender Card	264
QPC471, QPC775 Clock Controller Card	270
QPC477 Bus Terminating Unit	273
QPC513, QPC841 Serial Data Interface Card	274
QPC579 CPU Function Card	276
QPC580 CPU Interface Card	278
QPC584 Mass Storage Interface Card	280
QPC659 Dual Loop Peripheral Buffer Card	283
QPC687 CPU Card	285
Replacing the QPC723A Circuit Card	287
QPC742 Floppy Disk Interface Card	289
QPC940 ROM Card	292
Replacing the Security Device on the NT5D61 IODU/C	293
Replacing the Security Device on a redundant system	294

Replacing the Security Device on an option 51C system	297
Replacing NT5D20 IOP/CMDU cards or NT6D63 IOP and NT6D64 CMDU cards with NT5D61 IODU/C cards	302
Replacement procedures for redundant systems (options 61C, 81, 81C) 303	
Splitting the cores	304
Replacement procedure for option 51C systems	328
Completing the upgrade	343

Replacing an NT7D10 PDU with an NT7D67CB PDU 345

List of figures

Figure 1	
Static discharge points	10
Figure 2	
Disk position	12
Figure 3	
Locking latches on the module cover	16
Figure 4	
Removing the pedestal grill	17
Figure 5	
Removing air exhaust grill	18
Figure 6	
Removing air intake grill	18
Figure 7	
Air exhaust grills on the top cap	19
Figure 8	
Top cap assembly	20
Figure 9	
Connector for the battery pack assembly	23
Figure 10	
EEPE access plates (rear view)	31
Figure 11	
NT6D52 Rectifier and QBL15 Power/Battery Distribution Box connections	
105	

Figure 12	
NT7D10 Power Distribution Unit DC	141
Figure 13	
Cabling between the PDU and the field wiring terminal block	143
Figure 14	
Dual circuit breaker and associated module power supplies	147
Figure 15	
NT7D67CB Power Distribution Unit DC	151
Figure 16	
Field wiring terminals in the NT7D67CB PDU	152
Figure 17	
NT8D22 System Monitor in an AC-power pedestal	172
Figure 18	
Air exhaust grills on the top cap	177
Figure 19	
Top cap assembly	177
Figure 20	
Mounting for the column LED	178
Figure 21	
Thermostat harness	179
Figure 22	
Routing the thermostat harness from the top cap	180
Figure 23	
Installing the column LED	180
Figure 24	
Aligning the thermostat harness connector	181
Figure 25	
Air exhaust grills in the top cap	182
Figure 26	
Top cap assembly	183
Figure 27	
Air probe harness	184

Figure 28	
Connector for the air probe harness	184
Figure 29	
Routing the air probe harness from the top cap	185
Figure 30	
NT8D52 Blower Unit	186
Figure 31	
NT8D53AB Power Distribution Unit AC	188
Figure 32	
Connections at the field wiring terminal	189
Figure 33	
NT8D53AD Power Distribution Unit (option 21A)	191
Figure 34	
Mounting screws for the MPDU	195
Figure 35	
Connector for the battery pack assembly	239
Figure 36	
Blower unit and air filter in the front of the pedestal	253
Figure 37	
Pull-tab locations on the air filter	254
Figure 38	
NT7D10 Power Distribution Unit DC	347
Figure 39	
Cabling between the PDU and the field wiring terminal block	349
Figure 40	
Dimensions for drilling holes on the pedestal	350
Figure 41	
NT7D67CB Power Distribution Unit DC	351
Figure 42	
Field wiring terminals in the NT7D67CB PDU	354

List of tables

Table 1	
Translation from keyboard to telephone dial pad	6
Table 2	
DDP general purpose switch settings	51
Table 3	73
Table 4	
Network loop codes	77
Table 5	
Typical CNI configurations	207
Table 6	
Option 81C NTND95AA cable connections to 3PE cards	208
Table 7	
Option 81 CNI to 3PE connections—NTND14 cables	209
Table 8	
Extender codes	210
Table 9	
Network loop codes	210
Table 10	
DCH mode and address select switch settings	234
Table 11	
DDCH daughterboard address select switch settings	235
Table 12	
Peripheral signaling card numbers	259

Table 13	
Extender codes	260
Table 14	
Extender codes	265
Table 15	
Peripheral signaling card numbers	267